

Installation




Pre drill pilot hole with impact wrench (this determines holding power). Earth Anchor can then be installed. NB Pilot drill should be as close to anchor length as possible.



AND THE RESIDENCE OF THE PROPERTY OF THE PROPE



to) as load, this will take pressure off the anchor



Determining load capacity for any anchor application is an inexact science limited by an inexact environment, but carefully conducted testing can provide useful decision-making data. A further awareness of the many variables involved can guide an informed choice of an effective anchoring solution. Due to the array of unknowns both below and above the surface of any anchoring application – the soil medium, installation method, local climate, connections to the anchored structure – no one can guarantee a specific holding strength. Our published load capacity numbers, tested in actual field conditions to the best standards that real dirt can provide, are offered as an informed guideline, not a guarantee. The only method of accurately predicting the pullout capacity of any anchor at any specific site is by an on-site proof test of the anchor under local conditions, installed and loaded in the same manner as for the intended application.

Earth Anchors - Installation Method



Guying Tips


When guying off an anchor a cable is required as the aluminium needs support right around the head. Attach the cable to the load binder and attach under the head of the anchor. Anchors must be installed flat to the ground.







accessories sold separately





installation tools There are three installation methods for Earth Anchors, depending on the anchor style:


By hand - PE9T

Square drive - PE14STD

Socket drive - PE9, PE10, PE18, PE18-33, PE26, PE26-33



For large Earth Anchors PE36 & Pe46, we recommend using a large impact wrench or an air impact wrench if you want to avoid using a ratchet.



New Zealand

52 Newton Street, PO Box 4370, Mount Maunganui New Zealand tel +64 7 579 0190 fax +64 7 579 0194 www.baytex.co.nz

Australia

tel 02 4340 4144 mob 0400 312 314

